



392 VACUUM RELOCATION

Battery Tray Drill Template

www.falconshocks.com


THIS TEMPLATE IS ONLY FOR 392 RUBICON

TOOLS NEEDED:


10mm socket or wrench



1/4in drill bit with power drill




Using a 10mm wrench or socket, remove the negative battery terminal first, then the positive.



Remove battery from tray.

Remove the two indicated bolts that mount to the top of the Vacuum Canister.

Remove the battery anchor bolt.



Place template as shown. Mark the new hole with a marker, then carefully drill with 1/4 inch drill bit.



Align the Vacuum Canister with the new hole, insert bolts and tighten.

Reinstall battery, anchor bolt, and terminals.

Cut out the provided
template below

